

# Handling Guidelines - Vents

## Handling Instructions

- Wear gloves or use rounded tweezers when handling the vents.
- Mounting surfaces should be clean and free of oils, particles, and other contaminants.
- Vents should be mounted on flat, vertical surfaces where liquids or other contaminants will not pool.
- Follow dispenser instructions when using an automated vent dispenser.
- For manual vent dispensing, roll the liner under the vent until the vent extends beyond the liner and becomes easily accessible.
- Do not pry the vent from the liner or fold the vent, as this could damage the vent.

## Assembly Instructions

- Accurate placement of the vents can be improved by using markings, a recessed area, or a target area in which the vent is centered over the vent hole in the device or housing.
- Apply light finger pressure to the adhesive ring to seal the vent to the device or housing.
- Do not attempt to reposition the vent after installation. This can cause damage to the vents.
- Allow at least 24 hours dwell time before using or testing the vent.

Please contact your Donaldson representative if you have any questions or concerns.

Australia • Austria • Belgium • Canada • China • Czech Republic • Denmark • France • Germany • Hungary • India • Indonesia • Japan • Malaysia • Mexico • Netherlands • New Zealand • Poland • Saudi Arabia • Singapore • Slovakia • South Africa • South Korea • Spain • Sweden • Switzerland • Taiwan • Turkey • United Arab Emirates • United Kingdom • United States



The Americas  
Minneapolis, MN  
+1-952-887-3874

[www.donaldson.com](http://www.donaldson.com)

Asia  
Hong Kong, China  
+852-2405-8319

Asia  
Japan  
+81-42540-4475

Asia  
Shanghai, China  
+86-21-6438-8899

Europe  
Leuven, Belgium  
+32-16-383985