



Donaldson
FILTRATION SOLUTIONS

HANDLING GUIDELINES - VENTS

Integrated Venting Solutions

HANDLING INSTRUCTIONS

- Wear gloves or use rounded tweezers when handling the vents.
- Mounting surfaces should be clean and free of oils, particles, and other contaminants.
- Vents should be mounted on flat, vertical surfaces where liquids or other contaminants will not pool.
- Follow dispenser instructions when using an automated vent dispenser.
- For manual vent dispensing, roll the liner under the vent until the vent extends beyond the liner and becomes easily accessible.
- Do not pry the vent from the liner or fold the vent, as this could damage the vent.

ASSEMBLY INSTRUCTIONS

- Accurate placement of the vents can be improved by using markings, a recessed area, or a target area in which the vent is centered over the vent hole in the device or housing.
- Apply light finger pressure to the adhesive ring to seal the vent to the device or housing
- Do not attempt to reposition the vent after installation. This can cause damage to the vents.
- Allow at least 24 hours dwell time before using or testing the vent.

Contact us to increase the reliability of your micro-electronics.

Donaldson Company, Inc.
Integrated Venting Solutions
PO Box 1299
Minneapolis, MN
55440-1299 U.S.A.
Tel +1 952-887-3874 (USA)

donaldson.com
ivs@donaldson.com

Vent Handling Guidelines (05/10)
© 2010 Donaldson Co., Inc. All Rights Reserved.
Information in the document is subject to change without notice.

Europe
Leuven, Belgium
+32-16-38-3985

Asia
Hong Kong, China
+852-2405-8319